- (e) Any defect or malfunction of winches that could endanger employees shall be reported immediately to the officer in charge of the vessel, and the winch shall not be used until the defect or malfunction is corrected.
- (f) Temporary seats and shelters for winch drivers that create a hazard to the winch operator or other employees shall not be used.
- (g) Except for short handles on wheel type controls, winch drivers shall not be permitted to use winch control extension levers unless they are provided by either the ship or the employer. Such levers shall be of adequate strength and securely fastened with metal connections at the fulcrum and at the permanent control lever.
- (h) Extension control levers that tend to fall due to their own weight shall be counterbalanced.
- (i) Winch brakes shall be monitored during use. If winch brakes are unable to hold the load, the winch shall be removed from service.
- (j) Winches shall not be used when one or more control points, either hoisting or lowering, are not operating properly. Only authorized personnel shall adjust control systems.
- (k) When winches are left unattended, control levers shall be placed in the neutral position and the power shall be shut off or control levers shall be locked at the winch or the operating controls.

§1918.54 Rigging gear.

- (a) Guy and preventer placement. Each guy or preventer shall be placed to prevent it from making contact with any other guy, preventer, or stay.
- (b) Guys. When alternate positions for securing guys are provided, the guys shall be so placed as to produce a minimum stress and not permit the boom to jackknife.
- (c) Boom placement. The head of the midship boom shall be spotted no farther outboard of the coaming than is necessary for control of the load.
- (d) Preventers. (1) Preventers shall be properly secured to suitable fittings other than those to which the guys are secured, and shall be as nearly parallel to the guys as the fittings will permit.
- (2) Unless the cleat is also a chock and the hauling part is led through the

- chock opening, the leads of preventers to cleats shall be such that the direction of the line pull of the preventer is as parallel as possible to the plane of the surface on which the cleat is mounted.
- (3) Guys and associated preventers shall be adjusted to share the load as equally as possible where cargo operations are being conducted by burtoning. Exception: Where guys are designed and intended for trimming purposes only, and the preventer is intended to do the function of the guy, the guy may be left slack.
- (e) Cargo falls. Cargo falls under load shall not be permitted to chafe on any standing or other running rigging. Exception: Rigging shall not be construed to mean hatch coamings or other similar structural parts of the vessel.
- (f) Bull wire. (1) Where a bull wire is taken to a winch head for lowering or topping a boom, the bull wire shall be secured to the winch head by shackle or other equally strong method. Securing by fiber rope fastening does not meet this requirement.
- (2) When, in lowering or topping a boom, it is not possible to secure the bull wire to the winch head, or when the topping lift itself is taken to the winch head, at least five turns of wire shall be used.
- (g) Trimming and deckloads. When deck loads extend above the rail and there is less than 12 inches (30.48 cm) horizontal clearance between the edge of the deck load and the inside of the bulwark or rail, a pendant or other alternate device shall be provided to allow trimming of the gear and to prevent employees from going over the side.

[62 FR 40202, July 25, 1997, as amended at 65 FR 40945, June 30, 2000]

§ 1918.55 Cranes (See also § 1918.11).

The following requirements shall apply to the use of cranes forming part of a vessel's permanent equipment.

- (a) Defects. Cranes with a visible or known defect that affects safe operation shall not be used. Defects shall be reported immediately to the officer in charge of the vessel.
- (b) Operator's station. (1) Cranes with missing, broken, cracked, scratched, or